

Code	Description
73946	Volute spring
73938	Drive arm
73939	Spring,drive arm
73940	Return spring
73942	Clip spring
73943	Starter plate
73941	Start wheel
73944	starter rope
73945	Starter handle
73936	Pan head bolt with cross recess
73937	Flat gasket
74040	Recoil Starter assy
74002	Inner cover,exhaust
74003	Carburetor Seal gasket
74004	heatproof Plate
74007	Woodruff key
74008	Oil pressure alarm
74035	belt
74040	Recoil Starter assy
73951	Woodruff key oil seal
74011	Rubber seal ring
73961	O-ring

73833	O ring
74103	Oil filling plug
74573	Gasket,exhaust cap
74245	Anode
73820	Thermostat 60°
74054	Gasket,Thermostat
74017	O ring,filter
73951	Woodruff key oil seal
74023	Oil seal(bottom),crankshaft
74024	Oil seal(upper),crankshaft
73890	Circlip
74418	Rubber sleeve,Handle
74421	Handle
73905	locking segment
74415	Insert,handle
74422	Throttle lever
73798	emergency stop switches assy
74025	Throttle cable
74001	Shift handle
74041	Tiller Assy.
73993	Trim rod
73994	Orifice plate
74406	Clamp plate
73995	Clamp Bolt,Transom

73996	intensify handle
73997	Bolt
73866	Fuel hose joint assy
73986	Protecting bush,choke
73983	lock handle
74078	Drain bolt M14*12*1.5
74572	Damper A
73969	Water pump housing comp.
73968	Seal Gasket,water hose
73981	Woodruff key
73970	O ring,water pump casing
74430	Bearing seat casing
74027	Gasket,bearing seat
74243	Anode
74029	Oil seal
74087	Circlip
74089	Pin
74030	Oil seal
74032	O ring
74031	O ring
73971	Insert, cartridge
74042	Lower Casing Assy.
74043	Lower Casing Assy.
73944	starter rope
74177	Fuel Hose With Cinnecter